


Ruapehu Hut – new pump pictures (installed 29/09/12)

revised 02/05/14

Priming tube – comes from bench top – pour water in top through funnel before turning pump on (same as before)



The priming lever now has a wooden lever with a black mark at one end. Push the mark for 2 seconds to prime the pump.



Remember to check water level in tank before trying to run pump.